

# Dynamic tracking of lithium volume in a lithium-ion battery, using synchrotron X-ray tomographic microscopy

Patrick Pietsch


30.04.2015



## Measurement setup & goal of analysis

**Goal:**

Quantify reduction of lithium volume due to electrochemical reactions in the battery.




Dienstag, 2. Juni 2015

D-ITET / Institute for Integrated Systems / Laboratory for Nanoelectronics

2

## Cross sectional view through battery



⇒ 48 tomographic datasets, each with 1024x1024x600 voxels

⇒ Used Matlab for image processing


## Standard threshold segmentation impossible

Attempt standard thresholding...

⇒ No chance

**Strategy (exploit edge enhancement):**

- 1) Segment the edges
- 2) Enhance the edges to form a closed contour
- 3) Select only the enclosed domain
- 4) Clean remaining artifacts




Dienstag, 2. Juni 2015

D-ITET / Institute for Integrated Systems / Laboratory for Nanoelectronics

4

## Raw data



Dienstag, 2. Juni 2015

D-ITET / Institute for Integrated Systems / Laboratory for Nanoelectronics

5

## Wiener filter

**Function:**


wiener2

**Goal:**

reduce noise while keeping  
all important edge structures

**Parameters:**

3x3 neighborhood



Dienstag, 2. Juni 2015

D-ITET / Institute for Integrated Systems / Laboratory for Nanoelectronics

6



## Triangle thresholding

**Function:**

Self-written based on «Zack  
G.W. et al., *Journal of  
Histochemistry &  
Cytochemistry*, 1977»

**Goal:**

Segment as closely as  
possible above the grey  
value of lithium to keep all  
edge structures



Dienstag, 2. Juni 2015

D-ITET / Institute for Integrated Systems / Laboratory for Nanoelectronics

7

## Remove small connected domains («clean»)

**Function:**


Bwareaopen

**Goal:**

Avoid merging of undesired  
domains in the next step

**Parameters:**

Remove black domains with  
less than 5 connected  
voxels



Dienstag, 2. Juni 2015

D-ITET / Institute for Integrated Systems / Laboratory for Nanoelectronics

8

## Erode

**Function:**


imerode

**Goal:**

Merge disjoint boundaries

**Parameters:**

Structuring element: 3D ball  
with radius 2



## Remove small connected domains («clean»)

**Function:**

Bwareaopen

**Goal:**

Avoid merging of undesired  
domains in the next step

**Parameters:**

Remove black domains with  
less than 400 connected  
voxels



## Erode

**Function:**


imerode

**Goal:**

Merge disjoint boundaries

**Parameters:**

Structuring element: 3D ball  
with radius 2



## Remove small connected domains («clean»)

**Function:**


bwareaopen

**Goal:**

Avoid merging of undesired  
domains in the next step

**Parameters:**

Remove black domains with  
less than 8000 connected  
voxels





## Erode

**Function:**


imerode

**Goal:**

Merge disjoint boundaries

**Parameters:**

Structuring element: 3D ball  
with radius 4




## Pick only biggest connected domain in 3D

**Function:**

bwareacncomp

**Goal:**

Identify the biggest domain  
(which corresponds to  
lithium)



## Dilate

**Function:**


imdilate

**Goal:**

Dilate segmented domain  
back to original size

**Parameters:**

Structuring element: 3D ball  
with radius  $2+2+4=8$



## Remove rings

**Function:**

remove\_rings


Custom function from id19  
at ESRF (Lauridsen,  
Johnson, Tafforeau)

**Goal:**

Remove remaining artifacts

**Parameters:**

Threshold: 0.5



## Remove remaining holes

Function:

imfill


Goal:

Remove remaining  
enclosed domains



## Overlay result with segmentation


Overlay result with the  
original segmentation to  
check the quality of the  
results



## 3D rendering: Electrochemical shrinking of lithium electrode


Initial lithium electrode

Surface



Dynamic lithium electrode

Surface



## Compare result to coulomb counting from battery charger

Charge «stored» in the lithium is related  
to the volumetric shrinking via

$$Q(t) = - \frac{F * \rho_{Li}}{M_{Li}} * (V_{Li}(t) - V_{Li}(0))$$

Fairly good agreement to  
electrochemical data!

